



## MicroMat 16-38/46 Service Indicator Resetting Guide.

Please note that the service indicator should only be reset following the completion of a full annual service by a suitably qualified engineer.

Control Panels Button	Length of Press	Screen Display Following Successful Button Press
Red Menu/Reset	Press & Hold For at Least 5 Seconds	'Please Wait' or 'No Demand' followed by Menu followed 'Party 0 Hours'
Black -	Repeatedly Press and Release until Installer __ appears on the display	Installer __
Red Menu/Reset	Press and Release	Installer __ Flashes
Blue +	Repeatedly Press and Release until Installer 21 appears on the display	Installer __ changes to Installer 21
Red Menu/Reset	Press and Release	Curve or Pump Min
Blue +	Repeatedly Press and Release until Service In appears on the display	Service In ___ days
Red Menu/Reset	Press and Release	The number of days will flash and reset to 365
Red Menu/Reset	Press and Release	The number of days will stop flashing and store 365 limit
Blue +	Repeatedly Press and Release until Back appears on the display	Back
Red Menu/Reset	Press and Release	The display should return to the standard display